




Lenco 122 Double Rocker Switch Trim Tab System

(FOR USE WITH 12V SINGLE ACTUATOR SYSTEMS)



SWITCH OPERATION

The operation of the 122 Rocker Switch is based on the position of the bow. To lower the starboard bow, press the right (Stbd) side of the switch where it reads "DOWN". This lowers the port tab. To lower the port bow, press the left (Port) side of the switch where it reads "Down". This lowers the starboard tab. To raise the starboard bow, press the right (Stbd) side of the switch where it reads "UP". This raises the port tab. To raise the port bow, press the left (Port) side of the switch where it reads "UP". This raises the starboard tab.

3 YEAR LIMITED WARRANTY

MAY 2011